


How to print UC2 with Prusa I3 MK3S:



Setup Cura for the Prusa i3

- Download Cura settings from <https://www.prusa3d.com/drivers/> and install according to instructions
- Go to:
https://manual.prusa3d.com/Guide/How+to+import+profiles+to+Cura/1421#_ga=2.216762066.53635997.1563870317-1002203748.1563870317
- Download the archive and unpack it somewhere
- Go to Cura and import the different .curapfile files one by one ->
Cura_OriginalPrusa_Profiles\Cura_3_6_0\mk3_cura_profiles\MK3_cura_profiles\04_Cura_layheight_profiles

Settings for UC2 prints


- For printing UC2 parts use profile MK3S_MK3_0,15_Optimal.
- Change infill to 50%.
- In general **no** support is necessary (especially for all bas-cubes and the Z-stage!)
- Material: Prusa Research Prusament PLA.
- Safe gcode to SD card.

Printing the parts with the Prusa

- Switch on the printer (on the back, right side).
 - Clean the steel sheet (build plate) with isopropylalcohol and tissue.
 - Insert SD card.
 - Push the control knob next to the screen (if SD card does not open automatically).
 - Choose Print from SD.
 - Choose your file.
 - Watch the first layer or two to see if they attach properly.
 - In case something goes wrong, press the reset button (X).
 - Wait till your print is finished.
-
- Wait for it to cool down to room temperature. You can see the heated temperature on the screen.
 - Remove the steel sheet.
 - Bend the steel sheet so the parts separate from it.



- Return the steel sheet to its correct position.



For more information – Printing Handbook

https://cdn.prusa3d.com/downloads/manual/prusa3d_manual_mk3s_en_3_11.pdf#_ga=2.211631766.2016905863.1563777341-710825333.1558506269

We print with PLA 1,75 mm!